## **Product Update...**



## **HOW TO ORDER**


Trim Tab kits come with two actuators with 6' leads, Deutsch connectors, blades and hardware. Extension harnesses are included except on heavy duty and high performance models.




Lenco switch kits are available with integrated or two piece panel and control box, both with power pigtails.


Choose either single or dual actuator switch kits to suit the trim system you are fitting.

20' Deutsch Connected Actuator Extension Harnesses may be needed and will work with any of the trim tab system kits (1 per actuator)



## Flybridge Kit Standard or LED key pad connecting to Integrated Tactile Switch Kit






Key pad & control box sold separately

NOTE: See cutout template on inside back cover of owners manual

Key pad and bezel dimensions and installation instructions



Align the centre bit of a 2 1/16" (5.24cm) hole saw with the cross hairs in the centre of the desired mounting area and drill straight down through the console, providing additional clearance for switch and electrical connection. Insert the switch into the console cutout then hand tighten the Bezel Locknut clockwise onto the back side of the key pad.